



CRN TECNOPART, S.A.

Sant Roc 30
 08340 VILASSAR DE MAR (Barcelona)
 Tel 902 404 748 - 937 591 484 Fax 937 591 547
 e-mail: crn@crntp.com [http:// www.crntecnopart.com](http://www.crntecnopart.com)



FASEC SERIES, SPEED REGULATORS SINGLE PHASE FANS

They act on the voltage (phase cut).

For condensators. As the temperature increases the speed.
For evaporators. Temperature decreases with increasing speed.
Mnuals. Selected speed manually.

PANEL MOUNTING

MODEL	W	USE
FASEC 33	500	CONDENSATOR
FASEC 43	500	EVAPORATOR
FASEC 53	500	MANUAL
FASEC 337	1000	CONDENSATOR
FASEC 437	1000	EVAPORATOR
FASEC 537	1000	MANUAL

All models require PTC (T)
 not included in delivery.

FASEC models 33, 43 and 53 do not include
 octal base.

**Fasec 53
 Fasec 537**



**Fasec 33 Fasec 337
 Fasec 43 Fasec 437**



WALL MOUNTING

MODEL	W	USE
WM 253	500	MANUAL

Require PTC (T)
 not included in delivery




WM 253

MODELS FOR INTERIOR OF CABINET

MODEL	W	USE
FASEC 100	1000	COND. AND EVAP.
FASEC 150	1000	MANUAL
FASEC 500	5000	COND. AND EVAP.
FASEC 550	5000	MANUAL

All models require PTC (T)
 not included in delivery.

The manual models require a
 potentiometer not included in delivery.




**Fasec 100
 Fasec 150
 Fasec 500
 Fasec 550**

IP 55 PROTECTION MODELS


MODELO	W	USE
FASEC 105	1000	COND AND EVAP.
FASEC 155	1000	MANUAL
FASEC 505	5000	COND. AND EVAP.
FASEC 555	5000	MANUAL

All models require PTC (T) not included in delivery.


The manual models require a potentiometer not included in delivery.



Fasec 105
Fasec 155




Fasec 505
Fasec 555



Evaporator Fan Operation

If the temperature decreases, speed increases



Condenser Fan Operation

If the temperature increases, the speed increases

ACCESSORIES

DESCRIPTION
PTC (T) for pipe
Potentiometer for manual control
Octal Socket, DIN rail

